


Accessories for PG 8056 & PG 8061 Dishwashers

Upper and Lower Baskets/Basket Carriers



O 891 Upper Basket with E 810
 67189101D

Included with dishwasher

- Plastic-coated wire basket
- Integrated spray arm, rear docking
- 2 hinged cup racks for 20 cups
- 2-stage height adjustment by 2"
- Vertical clearance 7 $\frac{1}{8}$ "
- 7 $\frac{1}{2}$ " H x 20 $\frac{1}{2}$ " W x 19 $\frac{1}{4}$ " D




O 892 Upper Basket
 67189201D

- With E 812 and 2 glass rails
- Plastic-coated wire basket
- Integrated spray arm, rear docking
- Vertical clearance 7 $\frac{1}{8}$ "
- 7 $\frac{1}{2}$ " H x 20 $\frac{1}{2}$ " W x 19 $\frac{1}{4}$ " D



O 899 Upper Basket Carrier
 67189901D

- Plastic-coated wire basket
- Integrated spray arm, rear docking
- 2-stage height adjustment by 2"
- Vertical clearance 7 $\frac{1}{8}$ "
- 7 $\frac{1}{2}$ " H x 20 $\frac{1}{2}$ " W x 19 $\frac{1}{4}$ " D



O 898 Upper Basket
 67189801D

- For PG 8061
- Stainless steel
- Integrated spray arm, rear docking
- Height adjustable by 2 $\frac{3}{8}$ "
- Vertical clearance 9 $\frac{1}{2}$ "
- 8 $\frac{1}{8}$ " H x 20 $\frac{3}{4}$ " W x 19 $\frac{1}{2}$ " D



O 885 Upper Basket Carrier
 67188501D

- Stainless steel
- Integrated spray arm, rear docking
- For 19 $\frac{3}{4}$ " x 19 $\frac{3}{4}$ " baskets
- Vertical clearance 5 $\frac{1}{8}$ "
- 4 $\frac{3}{4}$ " H x 20 $\frac{7}{8}$ " W x 20 $\frac{3}{8}$ " D



U 890 Lower Basket
 67189001D

Included with dishwasher

- Plastic-coated wire basket
- For inserts or plastic baskets sized 19 $\frac{3}{4}$ " x 19 $\frac{3}{4}$ "
- 4" H x 21" W x 20 $\frac{3}{8}$ " D



U 881 Lower Basket
 4906620

- Plastic-coated wire basket
- Fixed insert for 54 saucers
- For combination with E 809 top insert for 23 cups with 3 $\frac{1}{8}$ " diameter
- 7 $\frac{1}{8}$ " H x 20 $\frac{3}{8}$ " W x 20 $\frac{3}{8}$ " D



U 876 Lower Basket Carrier
 67187501D

- Stainless steel
- For baskets and various inserts sized 19 $\frac{3}{4}$ " x 19 $\frac{3}{4}$ "
- Vertical clearance 9 $\frac{1}{8}$ " *
- 2" H x 21 $\frac{1}{8}$ " W x 19 $\frac{3}{4}$ " D
- * With O 885 upper basket carrier

Inserts for Upper and Lower Baskets



E 816 Plate Insert
 67581601D

2 Included with dishwasher


- Plastic-coated wire basket
- For use in U 890 lower basket
- 2 positions possible:

Load arrangement without cutlery holder

- For 19 plates with 9 $\frac{1}{8}$ " diameter
- For 19 plates with 13" diameter

Load arrangement with cutlery holder

- For 16 plates with 9 $\frac{1}{8}$ " diameter
- For 16 plates with 13" diameter



E 216 Plate Insert
 3809080

- Plastic-coated wire basket
- For use in lower baskets
- For 15 plates with 9 $\frac{1}{2}$ " diameter
- Accommodates E 165 cutlery holder



E 810 Plate Insert
 67581001D

Included with dishwasher

- Plastic-coated wire basket
- For use in O 891 upper basket
- 33 saucers or 17 dessert plates



E 888 Plate Insert
 5018690

- Plastic-coated wire basket
- For use in U 890 lower basket
- For 9 plates with 14 $\frac{1}{4}$ " diameter or 18 plates with 11 $\frac{1}{2}$ " diameter
- Rests spaced 1 $\frac{1}{8}$ " apart
- Rest height 7"
- 7" H x 18 $\frac{1}{8}$ " W x 18 $\frac{1}{8}$ " D



E 809 Lower Basket Top Insert
 5018650

- Plastic-coated wire basket
- For use in U 881 lower basket
- For 23 cups with 3 $\frac{1}{8}$ " diameter
- 2 $\frac{1}{8}$ " H x 20" W x 19 $\frac{1}{2}$ " D



E 9 Insert
 3808260

- Plastic-coated wire basket
- For use in U 890 and U 876 lower baskets
- For pots, pans, bowls and dishes
- Rests spaced 1 $\frac{1}{8}$ " apart
- Rest height 4 $\frac{1}{4}$ "
- 4 $\frac{3}{8}$ " H x 8 $\frac{3}{8}$ " W x 16 $\frac{1}{2}$ " D




E 884 Insert
 5018680

- Plastic-coated wire basket
- For use in U 890 lower basket
- For 10 large trays or platters, max. size 19 $\frac{3}{4}$ " x 12 $\frac{3}{8}$ "
- Rests spaced 1 $\frac{1}{4}$ " apart
- Rest height 7"
- 7" H x 18 $\frac{1}{8}$ " W x 18 $\frac{1}{8}$ " D

Accessories for PG 8056 & PG 8061 Dishwashers

Inserts for Upper and Lower Baskets



E 205 Glassware Insert
3808980

- Plastic-coated wire basket
- For use in lower baskets
- For 17 glasses with 2 $\frac{5}{8}$ " diameter
- Perforated plate to reduce impact of water jets
- Max. glass height 10 $\frac{3}{4}$ "
- 8 $\frac{3}{4}$ " H x 9 $\frac{5}{8}$ " W x 19 $\frac{1}{2}$ " D




E 459 Glassware Insert
4326630

- Stainless steel
- For use in upper or lower baskets
- For 12 glasses with 2 $\frac{3}{4}$ " diameter
- Max. glass height 8 $\frac{3}{4}$ "
- 6 $\frac{3}{4}$ " H x 7 $\frac{1}{8}$ " W x 18 $\frac{1}{8}$ "



E 815 Glassware Insert
5018670

- Plastic-coated wire basket
- For use in U 890 lower basket
- For 10 beer glasses
- Rests spaced 3 $\frac{3}{4}$ " apart
- Rest height 9 $\frac{1}{2}$ "
- 10" H x 8 $\frac{3}{4}$ " W x 20 $\frac{1}{4}$ " D




E 437 Cutlery Insert
4326640

- Stainless-steel container with carrying handle
- For use in O 885 upper basket carrier and U 876 lower basket carrier
- 18 compartments, 2 $\frac{3}{8}$ " x 1 $\frac{3}{4}$ "
- 2 compartments, 2 $\frac{3}{8}$ " x 2 $\frac{3}{8}$ "
- 16 compartments, 1 $\frac{1}{4}$ " x 1 $\frac{3}{4}$ "
- 2 $\frac{3}{4}$ " H x 8 $\frac{3}{8}$ " W x 17 $\frac{1}{4}$ " D



E 165 Cutlery Holder
3808830

- 2 Included with dishwasher
- Plastic holder
- For use in E 218 insert
- 3 compartments, 2 $\frac{3}{4}$ " x 2 $\frac{5}{8}$ "
- 4 $\frac{3}{8}$ " H x 2 $\frac{3}{4}$ " W x 8 $\frac{5}{8}$ " D



E 167 Cutlery Holder
67616701D

- Plastic holder
- For use in U 506 plate basket
- 7 compartments
- 4 $\frac{1}{4}$ " H x 17 $\frac{3}{8}$ " W x 2" D



E 812 Glassware Insert
67581201D

- Plastic-coated wire basket
- For use in upper baskets
- For 7 glasses, 2 $\frac{3}{8}$ " diameter

Lower Baskets



U 504 Cutlery Basket
67650401D

- Plastic-coated wire basket
- Plastic cutlery holder
- 9 compartments sized 4 $\frac{1}{4}$ " x 4 $\frac{1}{4}$ "
- 5 $\frac{1}{4}$ " H x 19 $\frac{3}{4}$ " W x 19 $\frac{3}{4}$ " D



U 506 Plate Basket
67650601D

- Plastic-coated wire basket
- 8 rows
- Rests spaced 2 $\frac{1}{8}$ " apart
- Accommodates E 167 cutlery holder
- 3 $\frac{3}{8}$ " H x 19 $\frac{3}{4}$ " W x 19 $\frac{3}{4}$ " D



U 507 Bistro Basket
67650701D

- Plastic-coated wire basket
- Spacing (tall) 3 $\frac{5}{8}$ " or 4" or 3 $\frac{3}{8}$ "
- Spacing (low) 2 $\frac{1}{8}$ " or 2 $\frac{1}{2}$ "
- 6 $\frac{1}{2}$ " H x 19 $\frac{3}{4}$ " W x 19 $\frac{3}{4}$ " D



U 524/1 Glassware Basket
10094770

- Plastic-coated wire basket
- 4 rows for glasses with 4" diameter
- 7 $\frac{1}{4}$ " H x 19 $\frac{3}{4}$ " W x 19 $\frac{3}{4}$ " D



U 525/1 Glassware Basket
10094780

- Plastic-coated wire basket
- 5 rows for glasses with 3 $\frac{1}{4}$ " diameter
- 7 $\frac{1}{4}$ " H x 19 $\frac{3}{4}$ " W x 19 $\frac{3}{4}$ " D

Accessories for PG 8056 & PG 8061 Dishwashers


Glassware Baskets - Low Top Frame (for use with U 876 or U 890)*




- U 534 Glassware Basket**
 67653401D
- Plastic basket
 - For 16 glasses, 4½" diameter
 - Compartments: 4½" x 4½"
 - Basket: 4⅞" or 6⅞" or 9¼" H x 19¾" W (20⅞" incl. side runners) x 19¾" D



- U 535 Glassware Basket**
 67653501D
- Plastic basket
 - For 25 glasses, 3⅞" diameter
 - Compartments: 3⅞" x 3⅞"
 - Basket: 4⅞" or 6⅞" or 9¼" H x 19¾" W (20⅞" incl. side runners) x 19¾" D




- U 536 Glassware Basket**
 67653601D
- Plastic basket
 - For 36 glasses, 2⅞" diameter
 - Compartments: 2⅞" x 2⅞"
 - Baskets: 4⅞" or 6⅞" or 9¼" H x 19¾" W (20⅞" incl. side runners) x 19¾" D




- U 537 Glassware Basket**
 67653701D
- Plastic basket
 - For 49 glasses, 2½" diameter
 - Compartments: 2½" x 2½"
 - Baskets: 4⅞" or 6⅞" or 9¼" H x 19¾" W (20⅞" incl. side runners) x 19¾" D


Glassware Baskets - High Top Frame (for use with U 876)*



- U 544 Glassware Basket**
 67654401D
- Plastic basket
 - For 16 glasses with 4½" diameter
 - Compartments: 4½" x 4½"
 - Basket: 4⅞" or 8⅞" or 10½" H x 19¾" W (20⅞" incl. side runners) x 19¾" D



- U 545 Glassware Basket**
 67654501D
- Plastic basket
 - For 25 glasses, 3⅞" diameter
 - Compartments: 3⅞" x 3⅞"
 - Basket: 4⅞" or 8⅞" or 10½" H x 19¾" W (20⅞" incl. side runners) x 19¾" D



- U 546 Glassware Basket**
 67654601D
- Plastic basket
 - For 36 glasses, 2⅞" diameter
 - Compartments: 2⅞" x 2⅞"
 - Baskets: 4⅞" or 8⅞" or 10½" H x 19¾" W (20⅞" incl. side runners) x 19¾" D



- U 547 Glassware Basket**
 67654701D
- Plastic basket
 - For 49 glasses, 2½" diameter
 - Compartments: 2½" x 2½"
 - Baskets: 4⅞" or 8⅞" or 10½" H x 19¾" W (20⅞" incl. side runners) x 19¾" D

Universal Baskets (for use with O 885, U 876 or U 890)*



- U 502 Plate Basket**
 67650201D
- Plastic basket
 - 6 or 9 rows
 - Rests spaced 2⅞" or 1⅞"
 - 4⅞" H x 19¾" W x 19¾" D



- U 503 Cutlery Basket**
 67650301D
- Plastic basket
 - Suitable for ice-cream bowls
 - Narrow-mesh base
 - 4⅞" H x 19¾" W x 19¾" D



- U 508 Cup Basket**
 67650801D
- Plastic basket
 - 4 rows for cups sized 4" diameter
 - 4⅞" H x 19¾" W x 19¾" D



- U 520 Glassware Basket**
 67652001D
- Plastic basket
 - 36 compartments sized 2⅞" x 2⅞"
 - 4⅞" H x 19¾" W x 19¾" D

Lower Baskets (for use with U 876 or U 890)*



- U 313/2 Basket for Trays**
 67631305D
- Plastic basket with pre-fitted skids
 - Insert for 10 trays sized 20½" x 11½"
 - Rests spaced 1" apart
 - Rest height 16⅞"
 - 7⅞" H x 20⅞" W x 19⅞" D



- U 505 Multi-Purpose Basket**
 67650501D
- Plastic basket
 - Interior height 6⅞"
 - Coarse-mesh base
 - 7¼" H x 19¾" W x 19¾" D

*See Basket Combinations
 Chart for Further Details

Accessories for PG 8056 & PG 8061 Dishwashers

Accessories



ABL 50 Spacer Trim
67211401D

- Stainless steel
- Allows height adjustment to 28 $\frac{3}{8}$ " cabinet size
- Height 2"




UO 30-60/80 Base
67376103D

- Stainless steel
- Open base
- Can be bolted to machine
- 11 $\frac{1}{8}$ " H x 23 $\frac{3}{8}$ " W x 23 $\frac{3}{8}$ " D



UG 30-60/80 Base
67376104D

- Stainless steel
- Closed base
- Can be bolted to machine
- 11 $\frac{1}{8}$ " H x 23 $\frac{3}{8}$ " W x 23 $\frac{3}{8}$ " D



Base Conversion Kit
67211605D

- Stainless steel
- Non-continuous fascia with 2 brackets
- 5 $\frac{1}{8}$ " H x 23 $\frac{3}{8}$ " W x 5" D



1-80 Conversion Kit
67211603D

- Stainless steel
- Base fascia with 2 brackets, lid and rear panel to convert standard unit into freestanding unit




DOS G80/1 Dosing Module
67747025USA

- Dispenser module for liquid detergent
- 2 AC 208V 60Hz / 2 AC 240V 60Hz
- 7 $\frac{7}{8}$ " siphon for 5 liter canister
- Container empty indicator

Basket Combinations


	Plate Basket	Cutlery Basket	Multi-Purpose Basket	Cup Basket	Tray Basket	Glassware Baskets			Max. Vertical Clearance of Dishware
	U 502	U 503	U 505	U 508	U 313/2	U 520	U 534 - U 537	U 544 - U 547	
Upper Basket Carrier O 885	X	X		X		X			5 $\frac{1}{8}$ "
Lower Basket Carrier U 876	X	X	X	X	X	X	X	X	9 $\frac{1}{8}$ "
Lower Basket U 890	X	X	X	X	X	X	X		7 $\frac{7}{8}$ "

Glassware Baskets Height Configurations



Glass heights for all basket sets with low top frame:

- Max. 2 $\frac{3}{4}$ " without extenders and without top frame
- 4 $\frac{5}{16}$ " - 5 $\frac{1}{2}$ " with short extenders
- 6 $\frac{7}{8}$ " - 7 $\frac{13}{16}$ " with long extenders



Glass heights for all basket sets with high top frame:

- Max. 2 $\frac{3}{4}$ " without extenders and without top frame
- 5 $\frac{1}{2}$ " - 6 $\frac{3}{4}$ " with short extenders
- 7 $\frac{13}{16}$ " - 9 $\frac{1}{8}$ " with long extenders