Míele

prioto

30" Downdraft Hood Proud Mounting

DA 6881 Levantar

Shown: KM 3464 with DA 6881 Proud Mounted Please note: This information is subject to change

づけ mieleusa.com Specification Sheets TRS 09092019 PLAN



SPECIFICATIONS	
Overall Unit Dimensions	30" (762 mm) W x 25¹¹/₁₀" (652 mm) H (Unextended) x 4³/₄" (120 mm) D
Overall Canopy Height	16" (406 mm)
Built-In	
Minimum Opening Dimensions	$25^{15/_{16}}$ " (659 mm) W x $25^{13/_{16}}$ " (656 mm) H (Including Countertop) x $4^{1/_4}$ " (108 mm) D
Fan	
Fan Speeds	4
Maximum CFM	DA 6881 w/DAG 600 → 500 CFM DA 6881 w/DAG 1000 → 1000 CFM
Duct	
Duct Diameter	DAG 600 → 6" (150 mm) DAG 1000 → 10" (254 mm)
Electrical	
Electrical Requirements	120V, 60Hz,15A
Power Cable	Ventilation system must be hard wired
Shipping	
Shipping Weight	62 lbs (28.1 kg)
Shipping Dimensions	36 ⁷ / ₈ " W x 30 ⁵ / ₈ " H x 10 ⁷ / ₈ " D
Support	
Call Miele	(800) 999-1360
Miele Website	∽ືtwww.mieleusa.com
20/20 Link	² 020technologies.com


If you are planning to install an oven in front of the appliance, the appropriate installation advice and dimensions regarding cool air circulation must be observed.




DA 6881 w/DAG600 Item DA6881+internal DA 6881 w/DAG1000 Item DA6881+external



STANDARD ACCESSORIES



Single Support Bracket for One Cutout Installation



Two Support Brackets for One or Two Cutout(s) Installation

OPTIONAL ACCESSORIES



DAG 600 500 CFM Internal Blower



DAG 1000

1000 CFM External Blower



R2000

Reducing collar limits air flow to less than 300 CFM with DAG 600



DUU 2900


Recirculation kit for use with DAG 600



DKF18-900

Replacement OdorFree charcoal filter (Used with DUU 2900)





- ① The DAG 600 blower can be rotated and mounted with the exhaust air direction pointing up, to the left, to the right or down.
- 2 The connection box can be positioned anywhere in the cabinet.
- ③ Cover for use with the DAG 1000 external blower.

The DAG 600 blower or the cover for the DAG 1000 blower can also be installed in the same position at the back of the appliance.

Exhaust connection:

with internal DAG 600 blower: \emptyset 6" (150 mm). with external DAG 1000 blower: \emptyset 10" (254 mm).


Please refer to the cooktop manufacturer's instructions when installing in combination with a cooktop. The installation and safety distance requirements must be maintained.

The total output of a multi-burner gas cooktop must not exceed 73,800 BTU, with no single burner exceeding 16,500 BTU. Gas cooktops with a greater output cannot be used in combination with this downdraft.



OPTION 1 ONE CUTOUT INSTALLATION SPECIFICATIONS Cutout Dimensions for One (1) Cutout

Proud Mount Installation




Exhaust or recirculation mode with DAG 600 blower installed at the front of the downdraft. Exhaust ducting (\oslash 6" (150 mm))


- ① Exhaust ducting to the right or left.
- 2 Exhaust ducting downwards.
- a) Overhang of the cooktop
- b) Cooktop cutout
- ③ If the downdraft and cooktop are installed in separate cutouts, ensure adequate stability of the strip in between.

If the blower is to be installed at the back of the downdraft, ensure that there is adequate space for installation.





A support bracket is mounted on the downdraft extractor. It serves as a support for the cooktop when the downdraft extractor and the cooktop are installed in a common cutout .




The following situation, the support bracket should be replaced with two small angle brackets. The downdraft extractor and cooktop are installed in a common cutout, but the cutout for the cooktop is narrower ⁽²⁾.



OPTION 2

TWO CUTOUT INSTALLATION SPECIFICATIONS Cutout Dimensions for Two (2) Cutouts **Proud Mount Installation**

Allows for Installation with Proud Mounted Downdraft in Combination with Flush or Proud Mounted Combisets and Cooktops



Exhaust or recirculation mode with DAG 600 blower installed at the front of the downdraft. Exhaust ducting (\oslash 6" (150 mm))


- ① Exhaust ducting to the right or left.
- 2 Exhaust ducting downwards.
- a) Overhang of the cooktop
- b) Cooktop cutout
- ③ If the downdraft and cooktop are installed in separate cutouts, ensure adequate stability of the strip in between.

If the blower is to be installed at the back of the downdraft, ensure that there is adequate space for installation.




OPTION 2

INSTALLATION SPECIFICATIONS Two (2) Cutout Option with Support Brackets (Included)



Two Angle Support Brackets




Two small angle brackets are mounted on the downdraft extractor. They serve as a support for the downdraft extractor when the downdraft extractor and cooktop are installed in two separate cutouts.



EXTERNAL BLOWER DAG 1000

(Optional Accessory)






- ① Exhaust air connection
- Power cord feed-through (strain relief)



EXTERNAL BLOWER DAG 1000 - CONTINUED

(Optional Accessory)



Example: Installation on an external wall Example: Installation on a roof


The exhaust connection can be connected to either the front or back of the downdraft. For more information see the installation diagram for the downdraft.



Recirculation Kit DUU 2900

(Optional Accessory)








R2000 (Optional Accessory)





If you would like to reduce the environmental impact of your ventilation system by limiting the CFM output the Reducing Collar can be installed. It reduces the air flow to less than 300 CFM in use with DAG 600. Check local building codes for maximum CFM requirements.